

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Manufacturer's representative in the United Kingdom is Hasbro UK Ltd.,
Caswell Way, Newport, Gwent NP9 0YH. ☎ 00800 22427276.

SURFACE WASH ONLY.



© Disney
® and/or ™ & © 2003 Hasbro. All Rights Reserved.
© denotes Reg. U.S. Pat. & TM Office.
4083/4082 Asst PN 6239940000



Questions? Call: 1-800-327-8264

4083/4082 Asst.

AGES 3+




CRADLIN' CUB™* NALA

Thank you for purchasing this Lion King toy! For maximum play value, be sure to read and follow instructions carefully.



TO PLAY

- Cradlin' Cub™* Nala has an ON/OFF switch in her belly. To play, make sure switch is in "ON" position.
- To activate Nala, just give her a hug. She'll say, "My name is Nala."
- Nala responds when you tickle Nala's belly or rock her back and forth:
 - Each time you tickle Nala's belly she'll say one of 4 random phrases, such as "I like playing with you." She always laughs, and sometimes she roars!
 - When you rock Nala back and forth, she'll respond with one of 4 sleepy-time phrases, such as "I like snuggling with you." Sometimes she yawns, and sometimes she snores!If you keep rocking Nala, she will say all 4 phrases, with a brief pause in between.
- After 20 responses or 30 seconds of non-activation, Nala will say "Goodnight" and turn herself off. To reactivate, give her a hug.




I like snuggling with you!



Note: Even when Nala turns herself off, the toy is still using battery power while switch is in the "ON" position. To conserve batteries, move switch to "OFF" position when you're not playing with Nala.

TO REPLACE BATTERIES

Use a Phillips screwdriver to loosen screw in battery compartment door (screw remains attached to door). Remove door and remove old batteries. Insert 3 x 1.5V fresh "AA"/LR6 alkaline batteries. Replace door and tighten screw.



⚠ CAUTION: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly and always follow the toy and battery manufacturer's instructions.
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- 3) Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference.

Batteries should be replaced by an adult.

⚠ CAUTION:

- 1) Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
- 2) Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
- 3) Remove exhausted or dead batteries from the product.
- 4) Remove batteries if product is not to be played with for a long time.
- 5) Do not short-circuit the supply terminals.
- 6) Should this product cause, or be affected by, local electrical interference, move it away from the other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- 7) **RECHARGEABLE BATTERIES:** Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**